


DAVA

SPINNING REEL

FEGLT6000D

*Please order by parts number, not key number.



Key No	Part No	Description
1	Q36-4201	DRAG KNOB
2	170-4101	DRAG WASHER RETAINER
3	Q73-1901	KEY WASHER
4	Q83-8701	DRAG WASHER
5	Q37-7601	EARED WASHER
29	Q88-4201	SPOOL ASSY
7	Q35-3501	LINE STOPPER PLATE
8	Q34-5501	LINE STOPPER
9	Q34-5701	LINE STOPPER SPRING
10	Q41-6204	SPOOL WASHER (A)
11	G46-6206	SPOOL BALL BEARING
12	E09-6505	SPOOL BEARING WASHER
13	F05-0101	SPOOL WASHER (B)
14	Q36-3801	SPOOL WASHER (C)
15	Q79-7701	CLICK LEAF SPRING
16	Q79-8301	CLICK SPRING HOLDER
17	Q37-7501	SPOOL WASHER (D)
18	H99-5201	ROTOR NUT PACKING
19	Q87-5601	ROTOR NUT
20	Q87-5501	ROTOR NUT COLLAR
21	G52-9509	ROTOR NUT WASHER
22	H02-2701	ROTOR NUT SCREW
23	Q83-7202	ROTOR
24	H41-3601	BAIL TRIP LEVER SPRING
25	-----	-----
26	Q13-4601	BAIL TRIP LEVER
27	H41-7701	BAIL TRIP LEVER SCREW
28	Q13-4801	BAIL SPRING SHAFT
29	Q81-8801	BAIL SPRING SHAFT COLLAR
30	H64-0701	BAIL SPRING
31	Q83-7801	BAIL SPRING HOLDER
32	Q81-2001	BAIL SPRING HOLDER SPRING
33	Q80-8701	BAIL SPRING HOLDER PIN
34	Q81-2201	BAIL SPRING COVER SCREW
35	Q83-8001	BAIL SPRING COVER
36	Q83-7902	BAIL ARM
37	Q80-9101	BAIL ARM COLLAR
38	B33-9801	BAIL ARM RETAINER
39	Q81-0001	ROLLER COLLAR (A)
40	Q80-9901	ROLLER COLLAR (B)
41	Q80-9801	LINE ROLLER
42	Q80-9901	ROLLER COLLAR (C)
43	Q81-0101	ROLLER WASHER
44	Q89-5601	BAIL
45	Q80-9701	ROLLER SCREW COLLAR
46	373-1306	ROLLER SCREW WASHER
47	M39-8901	ROLLER SCREW

Key No	Part No	Description
48	Q41-6203	BAIL HOLDER WASHER
49	Q81-2301	BAIL HOLDER SCREW
50	G83-7101	MAGSEALED PLATE SCREW
51	375-4102	MAGSEALED PLATE SCREW WASHER
52	J28-9301	MAGSEALED PLATE
53	J21-2901	MAGSEALED O RING
54	Q36-3501	MAGSEALED COVER
55	-----	-----
56	J30-9101	ONEWAY CLUTCH
57	J02-1303	CLUTCH RING
58	Q19-5701	PINION BEARING PLATE SCREW
59	Q20-5901	PINION BEARING PLATE
60	G52-3405	PINION BALL BEARING (A)
61	Z70-0908	PINION DRIVE GEAR SET
62	G57-2501	PINION SPRING WASHER
63	G46-7108	PINION BALL BEARING (B)
64	J42-8101	PINION COLLAR
65	Q88-3101	BODY
66	Q88-3601	MAIN SHAFT
67	Q85-3003	OSCILLATING POST
68	Q84-5901	ANTI REVERSE CAM SPRING
69	Q88-3501	ANTI REVERSE CAM
70	Q85-2601	ANTI REVERSE LEVER
71	Q88-4101	REAR COVER
72	Q34-2901	REAR COVER SCREW
73	G64-4201	OSCILLATING GEAR WASHER
74	Q13-3501	OSCILLATING GEAR
75	B85-3101	OSCILLATING GEAR O RING
76	G52-2101	OSCILLATING GEAR BEARING WASHER
77	G46-7108	OSCILLATING GEAR BALL BEARING
78	H46-3401	OSCILLATING GEAR SCREW
79	G64-5301	DRIVE GEAR O RING
80	373-7808	DRIVE WASHER
81	635-4801	DRIVE BALL BEARING (A)
82	Q88-3901	SIDE COVER
83	Q85-2401	SIDE COVER SCREW (A)
84	Q34-2701	SIDE COVER SCREW (B)
85	Q85-2401	SIDE COVER SCREW (C)
86	Q67-6301	HANDLE ASSY
87	B86-1705	DRIVE BALL BEARING (B)
88	G52-5101	DRIVE BEARING RETAINER
89	G67-2401	HANDLE CAP O RING
90	Q36-4801	HANDLE CAP
91	H73-0801	SIDE COVER PACKING
92	J23-8801	PINION BEARING WASHER (A)
93	371-2834	PINION BEARING WASHER (B)