




BAITCASTING REEL

LEXA-LC300HL/300PWRL-P

Please order by parts number, not key number
 Veuillez indiquer le numéro de la pièce (Non "Key" No.)



Key No.	Part No.	Part Name	Key No.	Part No.	Part Name
1	330-3000	CLICK BUTTON	55	240-2930	WORM SHAFT GEAR
2	230-2830	RIGHT SIDE PLATE	56	140-1280	BALL BEARING
3	190-1270	CLICK PAWL	57	410-2550	PLATE
4	540-5990	SPACER	58	460-5290	SCREW
5	410-3350	PLATE	59	460-5370	SCREW
6	260-2400	GEAR	60	540-6600	WASHER
7	460-2930	SCREW	61	470-1970	DRIVE SHAFT
8	240-2820	COUNTER GEAR	62	540-7010	DRIVE SHAFT WASHER
9	460-5660	COUNTER GEAR SCREW	63	530-0860	A/R PAWL
10	550-6100	COUNTER ASSEMBLY	64	240-2550	A/R RATCHET
11	180-2600	COUNTER COVER	65	540-7030	WASHER
12	460-1980	SCREW	66	250-1360	DRIVE GEAR
13	460-6030	SCREW	67	540-6890	DRAG WASHER
14	510-6240	CLICK SPRING	68	540-8010	KEY WASHER
15	540-9770	WASHER	69	540-8030	EARED WASHER
16	240-2330	COG WHEEL	70	540-8080	WASHER
17	210-2580	COLLAR	71	540-8020	KEY WASHER
18	460-4900	SCREW	72	150-2200	GEAR SHAFT COLLAR
19	220-3120	SET PLATE	73	140-1370	ROLLER CLUTCH
20	460-3220	SET PLT SCREW	74	230-2820	LEFT SIDE PLATE
21	240-3090	SPOOL GEAR	75	460-7340	LONG SCREW
22	140-1550	BALL BEARING	76	510-6220	SPRING
23-26	701-1820	SPOOL ASSEMBLY	77	150-2060	BUSHING
27	410-1970	CLUTCH LEVER PLT	78	430-1061	BEARING RETAINER
28	090-0280	CLUTCH LEVER	79	430-1080	O-RING
29	410-1960	CLUTCH LEVER PLT	80	540-6850	SPACER
30	110-1048	FRAME	81	540-4340	SPACER
31	400-2570	PIN	82	380-2020	CAST CONTROL CAP
32	170-1271	CLUTCH CAM	83	460-4300	SCREW
33	410-2620	PLATE	84	460-4870	SCREW
34	400-3310	KICK LEVER PIN	85	140-0570	BALL BEARING
35	330-2850	KICK LEVER	86	540-1570	SPACING WASHER
36	460-1290	SCREW	87	510-5370	CLICK LEAF SPRING HOLDER
37	510-5170	SPRING	88	540-6390	DRAG SPRING WASHER
38	510-5140	KICK LEVER SPRING	89	540-9021	WASHER
39	410-2890	YOKE	90	700-7180	STAR DRAG
40	510-4430	YOKE SPRING	91	510-3260	LEAF SPRING
41	540-6020	WASHER	92	701-1840	HANDLE ASSEMBLY
42	260-1753	PINION GEAR	93	380-1810	HANDLE NUT
43	540-3950	WASHER	94	350-0310	HANDLE NUT PLATE
44	470-3390	WORM SHAFT	95	460-5390	HANDLE NUT PLATE SCREW
45	270-0810	LEVEL WIND GUARD	96	200-0580	RETAINER
46	490-1080	LINE GUIDE	97	200-0530	RETAINER
47	400-2540	LINE GUIDE PAWL	98	200-0570	E-CLIP
48	540-3980	WASHER			
49	380-0780	LINE GUIDE NUT			
50	550-1850	FRONT PLATE			
51	540-6060	WORM SHAFT WASHER			
52	460-4980	LONG SCREW			
53	540-9760	WASHER			
54	240-3200	WORM SHAFT GEAR			

LEXA-LC300PWRL-P SPECIAL PARTS		
Key No.	Part No.	Part Name
100	260-2360	PINION GEAR
101	250-1850	DRIVE GEAR
102	230-282P	LEFT SIDE PLATE
103	701-1830	HANDLE ASSEMBLY