


LEXA-LC300H/300PWR-P



Key No.	Part No.	Part Name	Key No.	Part No.	Part Name
1	330-3000	CLICK BUTTON	56	470-1951	DRIVE SHAFT
2	230-2770	LEFT SIDE PLATE	57	540-7010	WASHER
3	190-1270	CLICK PAWL	58	530-0860	A/R PAWL
4	540-5990	SPACER	59	240-2550	A/R RATCHET
5	410-3350	PLATE	60	540-7030	WASHER
6	460-2930	SCREW	61	250-1340	DRIVE GEAR
7	510-6230	CLICK SPRING	62	540-6890	DRAG WASHER
8	540-9770	WASHER	63	540-8010	KEY WASHER
9	240-2330	COG WHEEL	64	540-8030	EARED WASHER
10	210-2580	COLLAR	65	540-8080	WASHER
11	460-7400	SCREW	66	540-8020	KEY WASHER
12	220-3110	SET PLATE	67	150-2200	GEAR SHAFT COLLAR
13	460-3220	SET PLT SCREW	68	140-1370	ROLLER CLUTCH
14	240-3090	SPOOL GEAR	69	230-2760	RIGHT SIDE PLATE
15	140-1550	BALL BEARING	70	240-2820	COUNTER GEAR
16-19	701-1820	SPOOL ASSEMBLY	71	460-5390	HANDLE NUT PLT SCREW
20	410-1970	CLUTCH LEVER PLT	72	550-6100	COUNTER ASSEMBLY
21	090-0280	CLUTCH LEVER	73	180-2600	COUNTER COVER
22	410-1960	CLUTCH LEVER PLT	74	460-6030	SCREW
23	110-1038	FRAME	75	460-1980	SCREW
24	400-2570	PIN	76	460-4870	SCREW
25	170-1261	CLUTCH CAM	77	460-7340	LONG SCREW
26	410-2610	PLATE	78	510-6220	SPRING
27	400-3310	KICK LEVER PIN	79	150-2060	BUSHING
28	330-2840	KICK LEVER	80	430-1061	BEARING RETAINER
29	460-1290	SCREW	81	430-1080	O-RING
30	510-5162	SPRING	82	540-6850	SPACER
31	510-5130	KICK LEVER SPRING	83	540-4340	SPACER
32	410-2880	YOKE	84	380-2020	CAST CONTROL CAP
33	510-4430	YOKE SPRING	85	460-4300	SCREW
34	540-6020	WASHER	86	140-0570	BALL BEARING
35	260-1733	PINION GEAR	87	540-1570	SPACING WASHER
36	240-2460	WORM SHAFT GEAR	88	510-5370	CLICK LEAF SPRING HOLDER
37	470-3360	WORM SHAFT	89	540-6391	WASHER
38	270-081L	LEVEL WIND GUARD	90	540-9021	WASHER
39	490-1080	LINE GUIDE	91	700-7170	STAR DRAG
40	400-2540	LINE GUIDE PAWL	92	510-3260	LEAF SPRING
41	540-3980	WASHER	93	701-1840	HANDLE ASSEMBLY
42	380-0780	LINE GUIDE NUT	94	380-1810	HANDLE NUT
43	550-1890	FRONT PLATE	95	350-0310	HANDLE NUT PLATE
44	540-6060	WASHER	96	460-5390	HANDLE NUT PLATE SCREW
45	460-4980	LONG SCREW	97	200-0580	RETAINER
46	540-9760	WASHER	98	200-0530	RETAINER
47	240-3200	WORM SHAFT GEAR	99	200-1440	RETAINER
48	240-2480	SHAFT	100	200-0570	E-CLIP
49	240-2490	WORM SHAFT GEAR			
50	540-9740	WASHER			
51	140-1280	BALL BEARING			
52	410-2540	DRIVE SHAFT PLATE			
53	460-5290	SCREW			
54	460-5370	SCREW			
55	540-6600	WASHER			

LEXA-LC300PWR-P SPECIAL PARTS		
Key No.	Part No.	Part Name
102	260-2330	PINON GEAR
103	250-1820	DRIVE GEAR
104	230-276P	RIGHT SIDE COVER
105	701-1830	HANDLE ASSEMBLY