




KEY NO.
PARTS NAME

01. PALM SIDE COVER
02. CLICK PIN
03. CLICK SPRING
04. LOCKING DIAL
05. CONTROL DIAL SUPPORT
06. SCREW
07. CONTROL DIAL
08. COIL SPRING
09. COIL SPRING
10. PIN
11. O-RING
12. LOCK LEVER
13. TAP SCREW
14. SLIDE CAM
15. COIL SPRING
16. SPOOL COVER
17. TAP SCREW
18. MAGNET HOLDER ASSEMBLY
19. WASHER
20. BALL BEARING
21. RING
22. SPOOL ASSEMBLY (BALL BEARING 1EA)
23. TAP SCREW
24. TAP SCREW
25. TAP SCREW
26. FRONT SUPPORT
27. FRAME
28. RETAINER
29. TAP SCREW

KEY NO.
PARTS NAME

30. THUMB BAR
31. RETAINER
32. BUSH
33. BALL BEARING
34. LEVER WIND ASSEMBLY
35. LEVER WIND PIN
36. WASHER
37. NUT
38. PIPE
39. WORM SHAFT
40. BALL BEARING
41. WASHER
42. WARM PINION
43. RETAINER
44. SPRING
45. KICK LEVER
46. SPRING
47. CLUTCH CAM
48. TAP SCREW
49. CLUTCH
50. COIL SPRING
51. PINION
52. GEAR SIDE COVER ASSEMBLY
53. TAP SCREW
54. O-RING
55. BALL BEARING
56. RING
57. WASHER
58. COLLAR

KEY NO.
PARTS NAME

59. WASHER
60. TENSION KNOB
61. SCREW
62. HANDLE NUT CAP
63. NUT
64. HANDLE ASSEMBLY (BALL BEARING 4EA)
65. WASHER
66. STAR DRAG
67. SPRING WASHER
68. LEAF SPRING ASSEMBLY
69. WASHER
70. BALL BEARING
71. ONE WAY CLUTCH ASSEMBLY
72. BUSH
73. WASHER-D
74. WASHER-L
75. WASHER-A
76. WASHER-L
77. WASHER-D
78. WASHER-L
79. DRIVE GEAR
80. WASHER
81. RATCHET
82. GEAR
83. GEAR METAL
84. SCREW
85. BEARING PLATE
86. RETAINER
87. BALL BEARING