


Spartacus Maximus



KEY NO. PARTS NAME

01. HANDLE KNOB CAP
02. HANDLE KNOB
03. INSIDE HANDLE KNOB
04. HANDLE NUT
05. HANDLE NUT RETAINER
06. HANDLE ASSEMBLY
07. FRICTION WASHER
08. STAR HANDLE ASSEMBLY
09. DRAG SPRING WASHER
10. CLICK HOLDER
11. CLICK SPRING
12. BRIDGE WASHER
13. CONTROL CAP
14. CUSHION RUBBER
15. BRAKE WASHER
16. O-RING
17. RIGHT COVER
18. ONE WAY CLUTCH
19. ONE WAY COLLAR
20. DRAG WASHER A
21. DRAG WASHER B
22. DRAG WASHER C
23. DRAG WASHER D
24. DRIVE GEAR
25. WASHER
26. RATCHET
27. GEAR SHAFT
28. CONNECTING GEAR

KEY NO. PARTS NAME

29. STOPER
30. E-RING
31. FRONT COVER
32. CARRIAGE SCREW PIN
33. CARRIAGE SCREW GEAR
34. WASHER
35. GUIDE BUSHING-B
36. CARRIAGE SCREW
37. HOLDER GUIDE
38. PAWL CAP
39. RETURN PAWL
40. LINE GUIDE HOLDER
41. GUIDE BUSHING-A
42. E-RING
43. WASHER
44. STABILIZER BAR
45. SPRING
46. DIGITAL DIAL
47. BRAKE DISC COVER
48. SOUND PIN
49. SOUND SPRING
50. BRAKE BEAN
51. BRAKE DISC HOLDER
52. SPOOL ASSEMBLY
53. FRAME
54. CLUTCH LEVER L-PLATE
55. CLUTCH LEVER
56. CLUTCH LEVER R-PLATE

KEY NO. PARTS NAME

57. KICK LEVER SPRING
58. KICK LEVER
59. CLUTCH SPRING
60. CLUTCH CAM
61. CLUTCH LEVER PLATE
62. CAM PLATE
63. CLUTCH
64. CLUTCH SPRING
65. PINION GEAR
66. STOPPER SPRING
67. LEFT COVER
68. KEY PUSH LEVER
69. BRAKE CONTROL LEV
70. CLICK SPRING
71. BRAKE CAM PLATE
72. SPRING
73. BRAKE CAM
74. SPRING PLATE
75. LOCKCOVER
76. SPRING
77. SPOOL COVER
78. MAGNET PLATE
79. MAGNET HOLDER
80. MAGNET
81. BRAKE LOOP
82. BRAKE WASHER
83. STOPPER SPRING

NOTE:
B: BEARING
S: SCREW