




No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
185	"E" washer	449	Spring washer	740	Drive shaft	936	Bearing ring
211	Set plate screws	451	Handle nut washer	741	Drive gear	937	Alarm spring
215	Cover screw	460	Drive shaft shield	742	Shaft spacer	943	Handle knob screw
302	Star drag washer	463	Cast control spring	743	Drive shaft bushing	944	Handle lock ring
384	Ball bearing (S6700)	464	Click spring A	745	Drive shaft washer	1021	Yoke spring
389	Ball bearing (S695)	465	Bearingspring	750	Lever wind washer	1099	Fixing lever
391	One-waybearing	468	Yoke	754	Fixed screw	1100	Side part for Release bar
392	Ball bearing (S105)	473	Drag washer A	755	Cast controlscrew	1101	Clutch release yoke
393	Ball bearing (S128)	474	Drag washer B	756	Release bar	1102	Anti-reverseratchet
394	Ball bearing (S126)	564	Alarm pin	757	Close cover	1103	Clutch release bar
411	Cast control bracket	601	Washer 1	758	Handle arm	1104	Clutch dog
412	Yoke ratchet	631	Wrench	759	Thimble	1105	Clutch spring
432	Pinion gear	668	Side plate screws	760	Spool shaft	1106	Yoke plate
435	Clutch lever screw	670	Close cover screws	761	Thimble spring	1107	Clutch skid
437	One-waybearing tube	679	Washer 2	764	Spool	1108	Clutch lever bracket
438	Anti-reversenail	692	Knob cover	767	Lock set	1109	Right plate
440	Spool shaft nail	693	Handle knob (EVA)	768	Handle shaft coat	1110	Frame
443	Eared washer	724	Bearing washers	779	Loose sleeve screw	1111	Transitional board
444	Key washer A	725	Tension knob	873	Strike alert lever		
445	Key washer B	729	Star drag knob	920	Sound gear		
446	Anti-reverse dog	731	Handle bolt	921	T handle nail		
447	Anti-reverse plate	735	Reel foot	927	Alarm sound gear		
448	Click bracket	736	Sound spring plate	932	Bushing screw		