




No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
41	Reel foot cannulation 1	430	Drag control lever washer	601	The small washer
42	Reel foot	431	"O" ring	602	Handle knob screw
46	Reel foot screws	493	Sound spring	604	Spool shaft spring
47	Reel foot cannulation 2	515	Cover	630	"O" ring
48	Rod clamp	516	Spool shaft	631	Wrench
52	Handle arm	517	High speed pinion gear	650	Handle bolt
165	Fixed nuts	518	Drag plate undersleeve	655	Fixed plate
178	Set plate nail	519	Sound gear	665	Big ring
185	"E" washer	520	Spool cannulation	666	Small ring
207	Push slice screw	521	Embedded clip	668	Side plate screws
211	Set plate screws	523	Close cover	670	Close cover screws
215	Cover screw	524	Rear drag plate	672	Fixed plate screws
381	Ball bearing (S606)	525	Drag plate	674	Anti-loose screw
384	Ball bearing (S6700)	526	Right plate	679	Button washer
390	Ball bearing (S696)	528	Frame	680	Drive shaft coat washer
395	One-way bearing	530	Spool	710	Bearing washer
396	Handle washer	531	Drag control lever	828	Drive gear-high speed
397	Drive shaft	538	Front drag plate	831	Drive shaft coat
406	Set plate	539	Alarm sound gear	832	Drive shield
416	"E" washer	545	Fixed screws	847	Friction ring
417	Drag knob cover	546	Drive shaft washer	860	Drag tension knob
418	Sound coat	558	Handle shaft retainer	873	Strike alert lever
419	Pre-program key pin	561	Handle cover	900	Pre-program plate
420	Sound nail	562	Handle cover screw	901	Pre-program key
421	Bearing cover	563	Handle knob	910	Anti-reverse dog
423	Drag plate washer	564	Sound spring pin	943	Handle knob screw -- left teeth
424	Spool shaft screw	565	Sound spring plate	972	Pinion gear cover
425	Screw embedded clip	566	Spool ring	975	Spring cover for silence
426	Screw for bearing cover	567	Spool spring washer	980	T handle nail
428	Sound nail spring	572	Anti-reverse ratchet		
429	Bearing ring	598	Handle bolt washer		