




ARIA-65a PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21004883	Main body	705	27050159	Transmission gear
102	21020002	Bushing	708	27080060	Oscillating slider
105	21056633	Rotor cap	716	27160036	Oscillation slider plate
108	21081606	Cap	718	27180738	Main shaft
200	22004703	Side plate	719	27190025	Click gear
300	23005274	Rotor	722	27220009	Click gear washer
301	23012365	Bail arm	800	28005025	Anti-reverse/anti-re lever
304	23043535	Bail arm cover	800-1	28000255	Anti-reverse/anti-re lever
305	23050239	Kick lever	801	28010039	Anti-re lever spring
307	23071941	Bail holder	804	28040055	Anti-re lever pin
309	23090037	Bail arm support pin	808	28080047	Ratchet
310	23100070	Compression spring	809	28090040	Silent spring
313	23131935	Bail wire assy.	0910096	0910096	Ball bearing
315	23150075	Line roller	0920373	0920373	Washer
316	23160011	Bushing	0920151	0920151	Washer
317	23170008	Line rollerwasher	0920589	0920589	Washer
318	23180001	Rotor nut	0920246	0920246	Washer
400	240016327	Spool assy.	0930641	0930641	Screw
405	24050031	Drag washer retainer	0930060	0930060	Screw
412	24120019	Spool bushing	0930575	0930575	Screw
500	25006649	Handle assy.	09301546	09301546	Screw
504	25040007	Handle screw cap washer	0930763	0930763	Screw
513	25130904	Handle cap	0930471	0930471	Screw
600	26004378	Drag knob assy.	09301268	09301268	Screw
610	26100053	Drag washer	0930664	0930664	Screw
611	26110019	Eared washer	0930643	0930643	Screw
612	26120047	Key washer	09301538	09301538	Screw
612-1	26120030	Key washer	0930216	0930216	Screw
612-2	26120056	Key washer	0930819	0930819	Screw
700	27000264	Drive gear	0930623	0930623	Screw
702	27020927	Pinion gear			