




AV-1000-LE PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21004877	Main body	705-1	27050222	Transmission gear
105	21050163	Pinion bearing fixed plate	708	27080130	Oscillating slider
105-1	21056616	Pinion bearing fixed bushing	716	27160026	Oscillation slider plate
108	21081604	Cap	718	27180726	Main shaft
200	22004695	Side plate	719	27190025	Click gear
201	22011222	Main body decoration	722	27220009	Click gear washer
201-1	22011223	Side plate decoration	722-1	27220037	Click gear washer
300	23005269	Rotor	800	28000333	Anti-reverse/anti-re lever
301	23012362	Bail arm	800-1	28000402	Anti-reverse/anti-re lever
304	23043551	Bail arm cover	801	28010024	Anti-re lever spring
305	23050214	Kick lever	0910618	0910618	One way assy.
307	23071940	Bail holder	0910013	0910013	Ball bearing
309	23090051	Bail arm support pin	0910049	0910049	Ball bearing
310	23100085	Compression spring	0910039	0910039	Ball bearing
313	23131962	Bail wire assy.	0910335	0910335	Ball bearing
315	23150086	Line roller	0910215	0910215	Ball bearing
316	23160014	Line roller bushing	0920373	0920373	Washer
316-1	23160010	Line roller bushing	0920136	0920136	Washer
317	23170014	Line roller washer	0920590	0920590	Washer
318	23180019	Rotor nut	0920237	0920237	Washer
400	240016509	Spool assy.	0920600	0920600	Washer
405	24050042	Drag washer retainer	0930541	0930541	Screw
407	24070047	Extension spring	09301547	09301547	Screw
500	25006737	Handle assy.	0930307	0930307	Screw
504	25040007	Handle screw cap washer	0930928	0930928	Screw
513	25130932	Handle cap	0930060	0930060	Screw
600	26004655	Drag knob assy.	0930438	0930438	Screw
610	26100011	Drag washer	09301327	09301327	Screw
612	26120006	Key washer	09301518	09301518	Screw
612-1	26120054	Key washer	09301450	09301450	Screw
700	27000445	Drive gear	0930429	0930429	Screw
702	27020490	Pinion gear	0930830	0930830	Screw
705	27050153	Transmission gear			

209OKA09039101