




AV-1000a PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21004877	Main body	702	27020522	Pinion gear
105-1	21056616	Pinion bearing fixed bushing	705	27050153	Transmission gear
105-2	21050146	Pinion bearing fixed bushing	705-1	27050222	Transmission gear
108	21081604	Cap	708	27080130	Oscillating slider
200	22004695	Side plate	716	27160026	Oscillation slider plate
201	22011190	Main body decoration	718	27180835	Main shaft
201-1	22011191	Side plate decoration	719	27190025	Click gear
300	23005327	Rotor	722	27220009	Click gear washer
301	23012428	Bail arm	800	28000333	Anti-reverse/anti-re lever
304	23043579	Bail arm cover	800-1	28000402	Anti-reverse/anti-re lever
305	23050232	Kick lever	801	28010024	Anti-re lever spring
307	23072000	Bail holder	0910618	0910618	One way assy.
309	23090051	Bail arm support pin	0910013	0910013	Ball bearing
310	23100090	Compression spring	0910051	0910051	Ball bearing
313	23132025	Bail wire assy.	0910039	0910039	Ball bearing
315	23150086	Line roller	0910335	0910335	Ball bearing
316	23160014	Line roller bushing	0910215	0910215	Ball bearing
317	23170014	Line roller washer	0920590	0920590	Washer
318	23180005	Rotor nut	0920136	0920136	Washer
320	23200122	Rotor balance weight	0920235	0920235	Washer
400	240016720	Spool assy.	0920600	0920600	Washer
405	24050042	Drag washer retainer	0930541	0930541	Screw
407	24070047	Extension spring	09301547	09301547	Screw
412	24120038	Spool bushing	0930307	0930307	Screw
500	25006737	Handle assy.	0930928	0930928	Screw
513	25130942	Handle cap	0930060	0930060	Screw
515	25150002	Handle screw cap washer	0930438	0930438	Screw
600	26004655	Drag knob assy.	09301327	09301327	Screw
610	26100011	Drag washer	09301262	09301262	Screw
612	26120006	Key washer	09301450	09301450	Screw
612-1	26120054	Key washer	0930431	0930431	Screw
700	27000445	Drive gear	0930830	0930830	Screw