




AV-20a-CL PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21007178	Main body	705	27050099	Transmission gear
105	21050012	Pinion bearing fixed plate	708	27080096	Oscillating slider
105-1	21050038	Pinion bearing fixed bushing	716	27160008	Oscillation slider plate
108	21087029	Cap	718	27180527	Main shaft
108-1	21087030	Cap	719	27190025	Click gear
200	22007108	Side plate	722	27220010	Click gear washer
300	23007055	Rotor	800	28000333	Anti-reverse/anti-re lever
301	23011361	Bail arm	800-1	28000324	Anti-reverse/anti-re lever
304	23043941	Bail arm cover	801	28010024	Anti-re lever spring
305	23050091	Kick lever	0910496	0910496	Ball bearing
307	23073735	Bail holder	0910039	0910039	Ball bearing
309	23090002	Bail arm support pin	0910373	0910373	Ball bearing
310	23100048	Compression spring	0910091	0910091	Ball bearing
313	23134155	Bail wire assy.	0910215	0910215	Ball bearing
315	23150022	Line roller	0910013	0910013	Ball bearing
316	23160002	Line rotor bushing	0920376	0920376	Washer
318	23180005	Rotor nut	0920154	0920154	Washer
400	240012330	Spool assy.	0930438	0930438	Screw
405	24050001	Drag washer retainer	09301462	09301462	Screw
407	24070009	Extension spring	0930471	0930471	Screw
412-1	24120021	Spool bushing	09301263	09301263	Screw
413	24130002	Waterproof retainer	0930307	0930307	Screw
500	25004419	Handle assy	0930538	0930538	Screw
504	25040004	Handle screw cap washer	0930840	0930840	Screw
513	25130174	Handle cap	0930663	0930663	Screw
600	26004059	Drag knob assy.	0930541	0930541	Screw
610	26100011	Drag washer	0930621	0930621	Screw
612	26120006	Key washer	09301016	09301016	Screw
612-1	26120054	Key washer	0930055	0930055	Screw
612-3	26120032	Key washer	09301492	09301492	Screw
700	27000318	Drive gear	0930431	0930431	Screw
702	27020883	Pinion gear			

209OKA07802202