




AV-3000-LE PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21009358	Main body	705	27050099	Transmission gear
105	21050012	Pinion bearing fixed plate	708	27080096	Oscillating slider
105-1	21056571	Pinion bearing fixed plate	716	27160008	Oscillation slider plate
105-2	21050143	Pinion bearing fixed bushing	718	27180703	Main shaft
108	21081597	Cap	719	27190025	Click gear
200	22004687	Side plate	722	27220009	Click gear washer
201	22011166	Main body decoration	800	28000333	Anti-reverse/anti-re lever
201-1	22011169	Side plate decoration	800-1	28000324	Anti-reverse/anti-re lever
300	23005251	Rotor	801	28010024	Anti-re lever spring
301	23015025	Bail arm	0910648	0910648	Ball bearing
304	23049865	Bail arm cover	0910039	0910039	Ball bearing
305	23050206	Kick lever	0910013	0910013	Ball bearing
307	23073945	Bail holder	0910049	0910049	Ball bearing
309	23090051	Bail arm support pin	0910091	0910091	Ball bearing
310	23100107	Compression spring	0910335	0910335	Ball bearing
313	23131787	Bail wire assy.	0910215	0910215	Ball bearing
315	23150086	Line roller	0920310	0920310	Washer
316	23160014	Line roller bushing	0920376	0920376	Washer
316-1	23160010	Line roller bushing	0920590	0920590	Washer
317	23170014	Line roller washer	0920154	0920154	Washer
318	23180005	Rotor nut	0920237	0920237	Washer
400	240016267	Spool assy.	0930433	0930433	Screw
405	24050042	Drag washer retainer	0930541	0930541	Screw
407	24070009	Extension spring	09301252	09301252	Screw
500	25006610	Handle assy.	0930209	0930209	Screw
504	25040007	Handle screw cap washer	0930044	0930044	Screw
513	25130930	Handle cap	0930471	0930471	Screw
600	26004650	Drag knob assy.	09301462	09301462	Screw
610	26100011	Drag washer	09301265	09301265	Screw
611	26110005	Eared washer	0930794	0930794	Screw
612	26120007	Key washer	0930431	0930431	Screw
700	27000318	Drive gear	0930838	0930838	Screw
702	27020907	Pinion gear	0930673	0930673	Screw

209OKA09039301