




AV-300L PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	11001243	MAIN BODY ASSY.	702	17020322	PINION GEAR
105	11050006	WORM SHAFT BUSHING	703	17030006	WORM SHAFT GUARD
105-1	11050007	WORM SHAFT BUSHING	704	17040008	LINE GUIDE SUPPORT BAR
117	11170012	RETAINER NUT	705	17050013	TRANSMISSION GEAR
200	12001776	MAIN SIDE PLATE	707	17070004	TRANSMISSION GEAR
201	12010089	ANTI-RE PAWL	710	17100036	LINE GUIDE ASSY.
207	12070097	HOLDED PLATE	712	17120020	WORM SHAFT
208	12080036	SIDE PLATE COVER	713	17130002	LINE GUIDE PAWL CAP
211	12110035	ANTI-RE PAWL PIN	715	17150009	LINE GUIDE PAWL
215	12150015	HOLD PLATE BUSHING	800	18000014	CLUTCH CAM
215-1	12150029	HOLD PLATE BUSHING	801	18010007	CLUTCH SPRING
216	12160018	ANTI-RE PAWL SPRING	802	18020024	CLUTCH BAR
300	13000553	VICE SIDE PLATE	804	18040001	CLUTCH SLIDER
302	13020017	WASHER	805	18050001	PINION GEAR YOKE
302-1	13020005	BUSHING	806	18060001	YOKE SPRING
302-3	13020002	WASHER	29000001	29000001	E RETAINER
303	13030040	CLICK BUTTON	29000006	29000006	C RETAINER
304	13040001	CLICK PAWL	0910099	0910099	BALL BEARING
305	13050007	CLICK PAWL SPRING	0920283	0920283	WASHER
311	13110021	SIDE PLATE COVERS	0920157	0920157	WASHER
400	14000282	SPOOL ASSY.	0920114	0920114	WASHER
401	14010052	SPOOL CLICK GEAR	0920166	0920166	WASHER
500	15000272	HANDLE ASSY	0920066	0920066	WASHER
516	15160026	HANDLE NUT RETAINER	0920076	0920076	WASHER
600	16000042	CAST CONTROL CAP	0930586	0930586	SCREW
609	16090003	DRAG SPRING WASHER	0930589	0930589	SCREW
610	16100038	DRAG WASHER	0930651	0930651	SCREW
610-1	16100045	CARBON WASHER	0930626	0930626	SCREW
611	16110005	EARED WASHER	0930734	0930734	SCREW
612	16120027	KEY WASHER	0930609	0930609	SCREW
614	16140003	DRAG WASHER	0930196	0930196	SCREW
615	16150028	STAR DARG	0930219	0930219	SCREW
617	16170002	DRIVE GEAR SHAFT BUSHING	0930202	0930202	SCREW
618	16180002	WASHER	0930696	0930696	SCREW
700	17000200	DRIVE GEAR	0940025	0940025	O RING
701	17010075	DRIVE GEAR SHAFT ASSY.			

109OKA00157151