





AV-30a-CL PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO
100	21005026	BODY	708	27080095
105	21050027	PINION BEARING FIXED PLATE	716	27160007
105-1	21050036	PIN. BEARING FIXED PLATE	718	27180500
108	21087033	CAP	719	27190025
108-1	21087034	CAP	722	27220009
200	22004102	SIDE PLATE	722-1	27220037
300	23004309	ROTOR	725	27250020
301	23011362	BAIL ARM	800	28000242
304	23043942	BAIL ARM COVER	800-1	28000322
305	23050088	KICK LEVER	801	28010024
307	23073736	BAIL HOLDER	0910495	0910495
309	23090002	BAIL ARM SUPPORT PIN	0910039	0910039
310	23100001	COMPRESSION SPRING	0910051	0910051
313	23134096	BAIL WIRE ASSY.	0910091	0910091
315	23150022	LINE ROLLER	0910013	0910013
317	23170008	LINE ROLLER WASHER	0910015	0910015
318	23180005	ROTOR NUT	0910215	0910215
400	240012332	SPOOL ASSY.	0920376	0920376
405	24050031	DRAG WASHER RETAINER	0920150	0920150
407	24070006	EXTENSION SPRING	0920540	0920540
412-1	24120022	SPOOL BUSHING	0930058	0930058
413	24130003	WATERPROOF RETAINER	0930171	0930171
500	25004421	HANDLE ASSY.	0930471	0930471
504	25040004	HANDLE SCREW CAP WASHER	09301263	09301263
513	25130174	HANDLE CAP	0930643	0930643
600	26004062	DRAG KNOB	0930538	0930538
610	26100049	DRAG WASHER	0930840	0930840
611	26110018	EARED WASHER	0930663	0930663
612	26120042	KEY WASHER	0930575	0930575
612-2	26120043	KEY WASHER	0930626	0930626
612-1	26120054	KEY WASHER	09301016	09301016
700	27000322	DRIVE GEAR	0930055	0930055
702	27020340	PINION GEAR	0930062	0930062
705	27050105	TRANSMISSION GEAR	0930431	0930431



PARTS NAME
OSCILLATING SLIDER
OSCILLATION SLIDER PLATE
MAIN SHAFT
CLICK GEAR
CLICK GEAR WASHER
CLICK GEAR WASHER
TRANSMISSION GEAR BUSHING
ANTI-REVERSE/ANTI-RE LEVER
ANTI-REVERSE/ANTI-RE LEVER
ANTI-RE LEVER SPRING
BALL BEARING
BALL BEARING
BALL BEARING
BALL BEARING
BALL BEARING
BALL BEARING
BALL BEARING
WASHER
WASHER
WASHER
SCREW
SCREW
SCREW
SCREW
SCREW
SCREW
SCREW
SCREW
SCREW
SCREW
SCREW
SCREW
SCREW
SCREW
SCREW
SCREW
SCREW

209OKA07802302