




AV-30a-CL PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21005026	Main body	716	27160007	Oscillation slider plate
105	21050027	Pinion bearing fixed plate	718	27180500	Main shaft
105	21056578	Pin. bearing fixed plate	719	27190025	Click gear
108	21087033	Cap	722	27220009	Click gear washer
108	21087034	Cap	722	27220037	Click gear washer
200	22004102	Side plate	725	27250020	Transmission gear bushing
300	23004309	Rotor	800	28000242	Anti-reverse/anti-re lever
301	23011362	Bail arm	800	28000322	Anti-reverse/anti-re lever
304	23043942	Bail arm cover	801	28010024	Anti-re lever spring
305	23050088	Kick lever	910633	910633	Ball bearing
307	23073736	Bail holder	910039	910039	Ball bearing
309	23090002	Bail arm support pin	910051	910051	Ball bearing
310	23100001	Compression spring	910091	910091	Ball bearing
313	23134096	Bail wire assy.	910013	910013	Ball bearing
315	23150022	Line roller	910015	910015	Ball bearing
318	23180005	Rotor nut	910215	910215	Ball bearing
400	240012332	Spool assy.	920376	920376	Washer
405	24050031	Drag washer retainer	920150	920150	Washer
407	24070009	Extension spring	920540	920540	Washer
412	24120022	Spool bushing	930058	930058	Screw
413	24130003	Waterproof retainer	930171	930171	Screw
500	25004421	Handle assy.	930471	930471	Screw
504	25040004	Handle screw cap washer	9301263	9301263	Screw
513	25130174	Handle cap	930643	930643	Screw
600	26004062	Drag knob	930538	930538	Screw
610	26100049	Drag washer	930840	930840	Screw
611	26110018	Eared washer	930663	930663	Screw
612	26120042	Key washer	930575	930575	Screw
612	26120043	Key washer	930626	930626	Screw
612	26120054	Key washer	9301016	9301016	Screw
700	27000322	Drive gear	930055	930055	Screw
702	27020872	Pinion gear	9301491	9301491	Screw
705	27050105	Transmission gear	930431	930431	Screw
708	27080095	Oscillating slider			