




AV-4000-LE PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21004878	Main body	705	27050105	Transmission gear
105	21050027	Pinion bearing fixed plate	708	27080095	Oscillating slider
105-1	21056578	Pinion bearing fixed bushing	716	27160007	Oscillation slider plate
105-2	21050164	Pinion bearing fixed bushing	718	27180705	Main shaft
108	21081605	Cap	719	27190025	Click gear
200	22004696	Side plate	722	27220009	Click gear washer
201	22011224	Main body decoration	725	27250020	Transmission gear bushing
201-1	22011225	Side plate decoration	800	28000242	Anti-reverse/anti-re lever
300	23005270	Rotor	800-1	28000322	Anti-reverse/anti-re lever
301	23015025	Bail arm	801	28010024	Anti-re lever spring
304	23043552	Bail arm cover	0910649	0910649	Ball bearing
305	23050207	Kick lever	0910039	0910039	Ball bearing
307	23073945	Bail holder	0910013	0910013	Ball bearing
309	23090051	Bail arm support pin	0910049	0910049	Ball bearing
310	23100102	Compression spring	0910091	0910091	Ball bearing
313	23131788	Bail wire assy.	0910335	0910335	Ball bearing
315	23150086	Line roller	0910215	0910215	Ball bearing
316	23160014	Line roller bushing	0920540	0920540	Washer
316-1	23160010	Line roller bushing	0920376	0920376	Washer
317	23170014	Line roller washer	0920590	0920590	Washer
318	23180005	Rotor nut	0920154	0920154	Washer
400	240016510	Spool assy.	0920237	0920237	Washer
405	24050042	Drag washer retainer	0930044	0930044	Screw
407	24070009	Extension spring	0930575	0930575	Screw
500	25006696	Handle assy.	0930171	0930171	Screw
504	25040007	Handle screw cap washer	09301252	09301252	Screw
513	25130930	Handle cap	0930209	0930209	Screw
600	26004650	Drag knob assy.	0930055	0930055	Screw
610	26100011	Drag washer	0930471	0930471	Screw
611	26110005	Eared washer	09301265	09301265	Screw
612	26120006	Key washer	0930643	0930643	Screw
612-1	26120054	Key washer	0930429	0930429	Screw
612-2	26120007	Key washer	0930838	0930838	Screw
700	27000322	Drive gear	0930663	0930663	Screw
702	27020822	Pinion gear			