




AV-40b PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21003657	Mani body	702	27020903	Pinion gear
105	21050027	Pinion bearing fixed plate	705	27050105	Transmission gear
105-1	21056578	Pin. bearing fixed plate	708	27080095	Oscillating slider
108	21081305	Cap	716	27160007	Oscillation slider plate
200	22003569	Side plate	718	27180705	Main shaft
201	22010286	Main body decoration	719	27190025	Click gear
201-1	22010287	Side plate decoration	722	27220009	Click gear washer
201-2	22010321	Main body decoration	725	27250020	Transmission gear bushing
201-3	22010322	Side plate decoration	800	28000242	Anti-reverse/anti-re lever
300	23003911	Rotor	800-1	28000322	Anti-reverse/anti-re lever
301	23011106	Bail arm	801	28010024	Anti-re lever spring
304	23042402	Bail arm cover	0910633	0910633	Ball bearing
305	23050146	Kick lever	0910051	0910051	Ball bearing
306	23060910	Bail holder cover	0910091	0910091	Ball bearing
307	23071410	Bail holder	0910013	0910013	Ball bearing
309	23090002	Bail arm support pin	0910015	0910015	Ball bearing
310	23100005	Compression spring	0910039	0910039	Ball bearing
313	23131377	Bail wire assy.	0910215	0910215	Ball bearing
315	23150010	Line roller	0920540	0920540	Washer
318	23180005	Rotor nut	0920154	0920154	Washer
400	240011914	Spool assy.	0920376	0920376	Washer
405	24050042	Drag washer retainer	0930046	0930046	Screw
407	24070009	Extension spring	0930171	0930171	Screw
412-1	24120021	Spool bushing	0930471	0930471	Screw
500	25009838	Handle assy.	09301263	09301263	Screw
504	25040004	Handle screw cap washer	0930643	0930643	Screw
513	25130721	Handle cap	0930972	0930972	Screw
600	26002903	Drag knob assy.	0930840	0930840	Screw
610	26100011	Drag washer	0930639	0930639	Screw
611	26110005	Eared washer	0930575	0930575	Screw
612	26120006	Key washer	0930209	0930209	Screw
612-1	26120054	Key washer	0930438	0930438	Screw
612-2	26120007	Key washer	0930544	0930544	Screw
700	27000322	Drive gear			

209OKA09301401