




AV-55b-CL PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21003659	Main body	700	27000328	Drive gear
105	0910332	Pinion bearing fixed plate	702	27020854	Pinion gear
105-1	21056581	Ball bearing plate	705	27050100	Transmission gear
108	21081312	Cap	708	27080097	Oscillating slider
200	22003583	Side plate	716	27160009	Oscillation slider plate
201	22010288	Main body decoration	718	27180700	Main shaft
201-1	22010289	Side plate decoration	719	27190025	Click gear
201-2	22010323	Main body decoration	722	27220009	Click gear washer
201-3	22010324	Side plate decoration	725	27250020	Transmission gear bushing
300	23003900	Rotor	800	28000256	Anti-reverse/anti-re lever
301	23011799	Bail arm cover	800-1	28000330	Anti-reverse/anti-re lever
304	23042400	Bail arm cover	801	28010039	Anti-re lever spring
305	23050145	Kick lever	0910530	0910530	Ball bearing
306	23060908	Bail holder	0910281	0910281	Ball bearing
307	23071412	Bail holder	0910091	0910091	Ball bearing
309	23090030	Bail arm support pin	0910013	0910013	Ball bearing
310	23100069	Compression spring	0910015	0910015	Ball bearing
313	23131376	Bail wire assy.	0910215	0910215	Ball bearing
315	23150022	Line roller	0920154	0920154	Washer
318	23180001	Rotor nut	0920376	0920376	Washer
400	240011925	Spool assy.	0920545	0920545	Washer
405	24050031	Drag washer retainer	0930044	0930044	Screw
407	24070006	Extension spring	0930171	0930171	Screw
412-1	24120021	Spool bushing	0930471	0930471	Screw
412-2	24120022	Spool bushing	09301274	09301274	Screw
500	25009839	Handle assy.	0930643	0930643	Screw
504	25040004	Handle screw cap washer	09301015	09301015	Screw
513	25130721	Handle cap	09301085	09301085	Screw
600	26002903	Drag knob assy.	0930623	0930623	Screw
610	26100053	Drag washer	0930575	0930575	Screw
611	26110021	Eared washer	0930945	0930945	Screw
612	26120049	Key washer	0930046	0930046	Screw
612-1	26120056	Key washer	0930058	0930058	Screw
612-2	26120050	Key washer	0930544	0930544	Screw