




AV-6000 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21009359	Main body	705	27050100	Transmission gear
105	0910332	Pinion bearing fixed plate	708	27080097	Oscillating slider
105-1	21056581	Pinion bearing fixed plate	716	27160009	Oscillation slider plate
105-2	21050142	Pinion bearing fixed bushing	718	27180700	Main shaft
108	21081598	Cap	719	27190025	Click gear
200	22004688	Side plate	722	27220009	Click gear washer
201	22011197	Side plate decoration	725	27250020	Transmission gear bushing
201-1	22011196	Main body decoration	725-1	27250002	Transmission gear bushing
300	23005252	Rotor	800	28000256	Anti-reverse/anti-re lever
301	23012363	Bail arm	800-1	28000330	Anti-reverse/anti-re lever
304	23043531	Bail arm cover	801	28010039	Anti-re lever spring
305	23050210	Kick lever	0910530	0910530	Ball bearing
307	23071935	Bail holder	0910013	0910013	Ball bearing
309	23090037	Bail arm support pin	0910281	0910281	Ball bearing
310	23100070	Compression spring	0910091	0910091	Ball bearing
313	23131971	Bail wire assy.	0910015	0910015	Ball bearing
315	23150075	Line roller	0910215	0910215	Ball bearing
316	23160011	Line roller bushing	0920545	0920545	Washer
317	23170008	Line roller washer	0920589	0920589	Washer
318	23180001	Rotor nut	0920245	0920245	Washer
400	240016269	Spool assy.	0920373	0920373	Washer
405	24050031	Drag washer retainer	0920151	0920151	Washer
407	24070006	Extension spring	0920150	0920150	Washer
500	25006618	Handle assy.	0930044	0930044	Screw
504	25040007	Handle screw cap washer	0930575	0930575	Screw
513	25130930	Handle cap	0930171	0930171	Screw
600	26004650	Drag knob assy.	0930763	0930763	Screw
610	26100053	Drag washer	0930945	0930945	Screw
611	26110021	Eared washer	0930471	0930471	Screw
612	26120049	Key washer	09301271	09301271	Screw
612-1	26120056	Key washer	0930643	0930643	Screw
612-2	26120050	Key washer	0930964	0930964	Screw
700	27000328	Drive gear	0930819	0930819	Screw
702	27020853	Pinion gear	0930623	0930623	Screw

209OKA09038531