




KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	31000144	Body assy. (with main shaft)	404	34040031	Handle knob
102	31020046	Reel foot	405	34050008	Handle knob rivet
111	31110004	Click pawl	408	34080014	Spool reatiner
300	33000019	Drag knob	409	34090001	Spool reatiner spring
303	33030006	Holder plate	410	34100018	Spool cover assy.
304	33040014	Click pawl	413	34130008	Counter balance
305	33050018	Click pawl spring	416	34160003	Bearing bushing
314	33140001	Spring washer	420	34200001	Handle knob pad
315	33150002	Disk break	509	35090001	E type reatiner
332	33320006	Break block	901	29010001	Fixed washer
332-1	33320007	Break block	910	0910086	One way bearing
333	33330002	Compression spring	920	0920056	Washer
335	33350004	Clutch plate	920	0920077	Washer
336	33360002	Nut	930	0930081	Screw
400	34000276	Spool assy.	930	0930084	Screw
400-1	34000277	Spool	930	0930117	Screw
403	34030005	Click gear	930	09301219	Screw