





Si-10a PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO
100	21003103	MAIN BODY	611	26110013
105	21050012	PINION BEARING FIXED BUSHING	612	26120011
105-1	21050039	PINION BEARING FIXED PLATE	612-3	26120032
106	21060366	DRAG KNOB SEAT	700	27000226
108	21080467	CAP	702	27020472
200	22002837	SIDE PLATE	708	27080055
300	23003371	ROTOR	710	27100003
301	23011221	BAIL ARM	718	27180445
302	23020011	BAIL ARM SPRING	719	27190027
304	23041888	BAIL ARM COVER	722	27220009
305	23050080	KICK LEVER	800	28000260
306	23060690	BAIL HOLDER COVER	801	28010025
307	23071172	BAIL HOLDER	0910069	0910069
313	23130849	BAIL WIRE ASSY.	0910374	0910374
315	23150030	LINE ROLLER	0910039	0910039
317	23170006	LINE ROLLERWASHER	0910335	0910335
317-1	23170014	LINE ROLLERWASHER	0910071	0910071
318	23180019	ROTOR NUT	0920322	0920322
325	23250010	BAIL SCREW	0920319	0920319
326	23260114	BAIL ARM DECORATION	0920355	0920355
400	240013048	SPOOL ASSY.	0920388	0920388
405	24050004	DRAG WASHER RETAINER	0930433	0930433
407	24070026	EXTENSION SPRING	0930467	0930467
412-1	24120021	SPOOL BUSHING	0930237	0930237
500	25004006	HANDLE ASSY.	0930307	0930307
504	25040004	HANDLE SCREW CAP WASHER	0930537	0930537
513	25130474	HANDLE CAP	0930620	0930620
600	26001519	DRAG KNOB ASSY.	0930785	0930785
610	26100036	DRAG WASHER		



PARTS NAME
EARED WASHER
KEY WASHER
KEY WASHER
DRIVE GEAR
PINION GEAR
OSCILLATING SLIDER
TRANSMISSION PLATE
MAIN SHAFT
CLICK GEAR
CLICK GEAR WASHER
ANTI-REVERSE/ANTI-RE LEVER
ANTI-RE LEVER SPRING
BALL BEARING
BALL BEARING
BALL BEARING
BALL BEARING
ONE-WAY BEARING RETAINER
WASHER
WASHER
WASHER
WASHER
SCREW
SCREW
SCREW
SCREW
SCREW
SCREW
SCREW